
Assembly Instructions



ED06 - EDEN CONSOLE TABLE Assembly Instructions

Before You Start

Warnings

Please retain these instructions for future reference.

> Keep fittings out of children's reach and keep children well away from the assembly area.

> Ensure that this product is only used on firm, level ground.

> Periodically check all fittings and re-tighten as necessary.

> Do not sit or stand on your furniture.

> Avoid exposing the furniture to excessive heat or direct sunlight, as this can cause deterioration of the colour.

> Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Number of People Required to Assemble

2 persons are required to assemble this item.

Time to Assemble

Approximately 20 minutes required to assemble this item.

Tools required



Missing Parts or Issues

If you have any problems, please don't hesitate to get in touch with your retailer directly.

Do

> Spend a short time reading through this leaflet before you start.

> When you are ready to start, make sure that you have the right tools and plenty of space.

> Unwrap all packaging materials and place components on a clean surface to protect them from damage.

> The packaging should be used to protect the product during assembly.

> Carefully check that you have all parts before beginning assembly.

> tThe furniture should be assembled in the room that it is intended to be used in.

> Ensure the product is fully assembled as shown, and that all fixings are fully tightened before use.

> Wipe occasionally with a soft cloth slightly dampened with water, then buff with a dry clean soft cloth.

Don't

> Do not drag or pull your furniture.

> Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

> Never allow any kind of liquid to remain on your furniture.

> Absorption can cause wood to warp or finishes to delaminate.

> Do not place hot items (e.g. hot drinks) directly on to the surface. Make sure you always use a placemat or coaster.

Assembly Instructions



In order to prevent overturning this product must be used with the wall attachment device provided. Serious or fatal crushing injuries can occur from furniture overturning. To help prevent this :

. Use the wall attachment devices provided

. Never allow children to climb or hang on drawers, doors or shelves

. Do not overload drawers

. Place heaviest items in the lower drawers or shelves


. Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this

product

. Never open more than one drawer at a time

An attachment device is provided with your product. Fixings may be included, however please ensure that these are suitable for your wall type. If they are not, you will need to source suitable fixings for your wall type. If in doubt consult a qualified trades person.

Always ensure that any walls being drilled into are free from hidden electrical wires, water, and gas pipes. If in doubt consult a qualified trades person.



ED06 - EDEN CONSOLE TABLE Assembly Instructions

Getting to Know your Product

Components supplied. Please use this guide if you require replacement parts.

#	Dimensions	Visual	Qty	Ctn
А	H3cm X W120cm X D45cm		1pc	
В	H72cm X W35cm X D6cm		1pc	
С	H72cm X W15cm X D6cm		1pc	
D	H72cm X W15cm X D6cm		1pc	


Fixtures and Fittings

Main Fixtures and Fittings Supplied (10 Scale)													
Ref	Dimensions	Qty	mm		20	30	40	50	60	70	80	90	100
1	M6x20	24											
2	(M8x16	20		0									
									р				
Other Fixtures and Fittings Supplied (Not To Scale)													
Ref	Dimensions	v	'isual	Qty									


Main Fixtures and Fittings Supplied (To Scale)

Ref	Dimensions	Visual	Qty
3	4MM		1
4	25x50MM	60	2

Assembly Instructions



Assembly Instructions



ED06 - EDEN CONSOLE TABLE Care Guide

